



## Step #7

Lay the Covermate on the spa cover. Adjust the Coupler Piece and Support Arms so that the Coupler Piece is lying parallel to the spa cover's hinge about a 1/2" away. (See Fig.8) Using the #10 self tapping screws, fasten Support Arms to Pivot Arms and the Coupler Piece.

**Note:** Be sure to rotate the Coupler Piece so that the inserted screws are at a horizontal angle with heads facing the back of the spa.

## Step #8

Position Retainer Clips so that the vertical portion is centered between the two Cover Halves and the horizontal portion touching the underside of the cover is inset from the outside edge cover approx. 3/4" on the inside of the Cover Skirt. Using a #10 Self Tapping Tapping Screw - Screw Retainer Clip into final position. (See Fig.9)

## Step #9

Adjust length of Safety Lock Down Strap and attach Buckle portion to side of Spa (See Fig.10).

## Step #10

Using the Covermate, lift the Cover off the Spa and place in the upright position. Snap the Gas Shocks on to the Ball Studs.

**Note:** Be sure to install Gas Shocks with black body on top.

## Step #11

Slip the black hand grips to the edge of the spa cover and snap black plastic screw head covers on. You are done!

## Operation Of Covermate III

- 1) Fold the first half of the Spa Cover off the Spa.
- 2) Unbuckle Safety Lockdown Straps.
- 3) Gripping the Rubber Grip, motion the Spa Cover into the vertical upright position.
- 4) When closing Spa Cover unlock Wind Lock Bar by lifting up on the Bar and pulling the Covermate down.
- 5) Buckle Safety Lockdown Straps.